

Bebe Style MeGrow High Chair



Instruction Manual

To ensure safe, trouble free use, please take a little time to read the important safety notes and the instructions. **IMPORTANT: KEEP THIS INSTRUCTION MANUAL FOR FUTURE**

REFERENCE (To download visit www.bebestyle.co.uk)

It is strictly prohibited to use this product without adult supervision.

Maximum weight allowance is 60KG



IMPORTANT: KEEP FOR FUTURE REFERENCE

SAFETY: TAKE NOTE

Highchair

Thank you for choosing our product.

This highchair is carefully designed for baby's safety and features a large tray with cup holder and a wipe clean seat with five point harness.

Suitable for children who are able to sit up unaided (approximately 6-9 months up to 36 months.)

To ensure safe, trouble free use, please take a little time to read the important safety notes below and the following instructions.

- WARNING: Do not use if any part is broken, torn or missing.
- WARNING: Do not use the highchair until the child can sit up unaided.
- WARNING: Do not use the highchair unless all components are correctly fitted and adjusted.
- WARNING: Do not leave your child unattended, even for the shortest time.
- WARNING: To prevent serious injury or death from falls or sliding out, ensure the harness is correctly fitted and that the child is secure in the restraint.
- WARNING: Avoid placing the chair near naked heat sources such as electric bar fires, gas fires, etc. or where a child could gain access to any other kind of hazard.
- Ensure all locking devices work correctly & regularly check the locks & fittings for security.
- Only use on a flat stable surface.
- Ensure your highchair is fully erected before placing your child inside.
- Ensure children are clear of all moving parts before making any adjustments.
Do not move the highchair with your child inside.
- Do not allow your child to climb unassisted into, play with or hang onto your highchair. This is not a toy.
- All additional hazards such as electrical flex should be kept out of reach of the child in the highchair.
- Complies with EN 14988 : 2006.

CARE & MAINTENANCE

- Ensure all locking devices work correctly & regularly check the locks & fittings for security.
- Regularly check all parts for wear & tear.
- DO NOT use spray lubricants, simply wipe clean after use.

➤ To avoid suffocation dispose all plastic bags appropriately.

➤ This product complies with EN 14988-1/2:2006+AI:2012 & BS EN 12790:2009



IMPORTANT: KEEP FOR FUTURE REFERENCE

SAFETY: TAKE NOTE

Bouncer

**For up to 9KG or until baby can sit upright unassisted.
IMPORTANT! KEEP FOR FUTURE REFERENCE.**

⚠ WARNING:

1. Adult assembly required.
2. Never place a child over 9KG in the bouncer.
3. Always use restraint system.
4. Never use when the baby is able to sit upright unassisted.
5. Never leave child unattended.
6. Fall hazard: child's movement can slide bouncer. Never place product near edges of counter tops, tables, steps or other elevated surfaces. Always use on the flat.
7. This reclined cradle is not intended for prolonged periods of sleeping.
8. This reclined cradle does not replace a cot or a bed. Should your child need to sleep, then it should be placed in a suitable cot or bed.
9. Do not use accessories or replacement parts other than those approved by the manufacturer.
10. Never lift bouncer using the toy bar as a handle.
11. Never move unit while child is seating.
12. Stop using it only component broken or missing.
13. Remove all packaging and fastenings before baby use.


EXECUTIVE STANDARD:

Conforms to the Safety Requirements of ASTM F-963. EN12790:2009.

Details




Adjustable height of seat




Adjustable food tray

Parts






1



2




3



4



5



6



7

1. Supporting tube x 4 (two go in the seat fabric and two on the frame).
2. Foot rest x 1
3. Frame/ legs x 2 left & right.
4. Seat fabric x 1
5. Tray brackets x 2
6. Insert zip.
7. Side guard fabric x 2

4 Stages



0-6 Months



6 months – 8 years



8 Years +



Up to 60KG




Rocking chair



Highchair

Rocker Assembly 0 – 6 Months



1. Hold the frame horizontally with the tray brackets facing inwards, and bolt on two supporting frames as shown.
2. Then attach the second frame.
3. Place the seat/rocking seat fabric on the frame as shown.
4. Attach the two side guard fabrics as shown.

Highchair Assembly 6 Months +



- A. Feed the supporting tubes through the fabric, and then roll the fabric around the tubes to designated length needed.
- B. Attach the tube that is in the base of the seat fabric into the bracket on the chair legs.
- C. Attach top tube to the top of the chair base with 2 screws.



Tray Installation


Insert the two ends of the tray into the white brackets on the frame at the same time.




Use the two white sliding triggers on the tray to adjust the width of the tray to make it more comfortable for your little one.



To remove the tray pull back on the two sliding buttons on the tray and pull out the tray from the seat frame.



Highchair Assembly 8 Years +



Unravel the fabric in order to make the seat fabric longer.
Move the lower support tube to the lower holes in the seat frame.



From 8 years old

For adult use

WARNING: Never leave a child unattended in this product.

WARNING: Never attempt to tighten or loosen the screws with you child still in the chair.

Made in China

Bebe Style Ltd NW2 1BG

info@bebestyle.co.uk

www.bebestyle.co.uk



Complies with EN 14988-1/2:2006+A1:2012 & BS EN 12790:2009